

# USER MANUAL

## Purekeys Wireless Mouse

**Model:** PK-MRF-02

**FCC ID:** 2AELM-50075

**Part:** 50075(white mouse) and 50275(black mouse)




Figure 1

1. **Insert Batteries:** Unscrew the battery cover and insert 2 AAA (1.5V alkaline) batteries as shown in Figure 1. Replace the cover and silicone seal.
2. **Connect USB Dongle:** Start your PC and insert the USB dongle into a free USB port.
3. **Plug-and-Play:** It may take a few minutes for the drivers to install automatically. No additional drivers are required.
4. **Battery Check:** Press left and right buttons and check the LED on the bottom: **Green:** Battery OK. **Red:** Replace batteries.

## Touch Scroll Sensor

Swipe your finger forward or backward over the touch sensor located between the left and right buttons to scroll. Double-tap the touch sensor to simulate a middle button function.

## Cleaning Instructions

The silicone cover is designed for quick and thorough cleaning with hospital-grade disinfectants, including 70% alcohol.

1. **Activate cleaning mode:**
  - Press and hold the left and right buttons for **10 seconds to enter cleaning mode** (blinking green light). The mouse is now disabled to prevent unintended inputs.
2. **Clean the mouse:**
  - Use your preferred disinfectant solution to clean the surface.
3. **Reactivate the mouse:**
  - Press and hold left and right buttons for **4 seconds to exit cleaning mode**. The mouse is now ready for use.

## Compliance

Purekeys declares that this product complies with the essential requirements and other relevant provisions of the European Regulation 2004/108/EC.

## Responsible Party

Purekeys BV

Egersundweg 2 E, 9723 JM Groningen, Netherlands

Phone: +31507210810

Email: info@purekeys.com

**This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:**


- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

# Wireless mouse quick installation guide



unscrew 3 bottom screws




remove battery cover




place batteries as indicated




replace cover and tighten 3 bottom screws



press right and left mouse switch to check batteries



start PC and put dongle in free USB port



Installation will start automatically and may take 1 minute.

If any problems occur, read user manual or check FAQ on [www.purekeys.com](http://www.purekeys.com)